

# Switching Power Supply

# S8PS

## Compact DIN-Rail Mounting Industrial Power Supplies with Capacities Up to 600 W

- Models range from 50 W to 600 W.
- Universal input: voltage range 100 to 240 VAC.
- Power Factor Correction (PFC) on all models.
- UL508 approval on 100-W and 150-W models.
- DIN-rail mounting brackets provided (except with 600-W model).
- Protection-ON alarm indicators (300-W and 600-W models).
- UL, CSA, VDE, and CE approved.
- 3-year warranty.



## Ordering Information

**Stock Note:** Shaded models are normally stocked.

### ■ OPEN-FRAME TYPE

Rated input voltage	Power ratings	Output		Part number	
		Voltage	Current	Front-mounting bracket	DIN-rail mounting bracket
100 to 240 VAC	50 W	5 V	10 A	S8PS-05005	S8PS-05005D
		12 V	4.2 A	S8PS-05012	S8PS-05012D
		24 V	2.1 A	S8PS-05024	S8PS-05024D
	100 W	24 V	4.5 A	S8PS-10024	S8PS-10024D
	150 W	24 V	6.5 A	S8PS-15024	S8PS-15024D

### ■ COVERED TYPE

**Stock Note:** Shaded models are normally stocked.

Rated input voltage	Power ratings	Output		Part number	
		Voltage	Current	Front-mounting bracket	DIN-rail mounting bracket
100 to 240 VAC	50 W	5 V	10 A	S8PS-05005C	S8PS-05005CD
		12 V	4.2 A	S8PS-05012C	S8PS-05012CD
		24 V	2.1 A	S8PS-05024C	S8PS-05024CD
	100 W	24 V	4.5 A	S8PS-10024C	S8PS-10024CD
	150 W	24 V	6.5 A	S8PS-15024C	S8PS-15024CD

## ■ ENCLOSED TYPE

**Stock Note:** Shaded models are normally stocked.

Rated input voltage	Power ratings	Output		Part number	
		Voltage	Current	Front-mounting bracket	DIN-rail mounting bracket
100 to 240 VAC	300 W	24 V	14 A	S8PS-30024C	S8PS-30024CD
	600 W	24 V	27 A	S8PS-60024C	---

## ■ MODEL NUMBER LEGEND

S8PS-

1      2      3

### 1. Power Ratings

050: 50 W  
100: 100 W  
150: 150 W  
300: 300 W  
600: 600 W

### 2. Output Voltage

05: 5 V  
12: 12 V  
24: 24 V

### 3. Configuration

C: Covered type with Front-mounting Bracket  
D: Open-frame type with DIN Rail Mounting Bracket  
CD: Covered type with DIN Rail Mounting Bracket  
None: Open-frame type with Front-mounting Bracket

## ■ ACCESSORIES (SOLD SEPARATELY)

**Stock Note:** Shaded models are normally stocked.

Description	Length	Width	Part number
DIN-rail (See <i>Dimensions</i> section for details.)	0.5 m (1.64 ft)	7.3 mm (0.29 in)	PFP-50N
	1 m (3.28 ft)	7.3 mm (0.29 in)	PFP-100N
	1 m (3.28 ft)	16 mm (0.63 in)	PFP-100N2

# Specifications

Item	50 W	100 W	150 W	300 W	600 W
Efficiency (typical)	74 to 80% (depends on the model)				
Life expectancy (See Note 3.)	10 yrs. min. (used at 40°C at the rated input with a 50% load, standard installation)				
Input					
Voltage	100 to 240 VAC (85 to 264 VAC)				
Frequency	47 to 63 Hz				
Current (See Note 1.)	0.9 or 0.45 A max.	1.8 or 0.9 A max.	2.7 or 1.4 A max.	5.4 or 2.7 A max.	10 or 5 A max.
Power factor (See Note 1.)	0.95 TYP.				
Leakage current (See Note 1.)	0.5 or 1.0 mA max.				
Inrush current (25°C, cold start) (See Note 1.)	25 or 50 A max.				

(This table continues on the next page.)

- Note: 1. 100% load for rated input voltage (100 VAC or 200 VAC)
2. Mean Time Between Failures is calculated according to the probability of accidental device failures, and indicates reliability of devices. Therefore, it does not necessarily represent a life of the product.
3. The life expectancy shown in the above table indicates average operating hours under the ambient temperature of 40°C and a load rate of 50%. Normally this is determined by the life expectancy of the built-in aluminum electrolytic capacitor. It must be noted that the life expectancy of the fan built into the 600-W model is not included.
4. The weight indicated is for the open-frame type. (Includes the cover for 300-W and 600-W models.)

Specifications Table – continued from previous page


Item	50 W	100 W	150 W	300 W	600 W
Output					
Voltage adjustment range	–5% to 10%				
Ripple (See Note 1.)	2% (p–p) max.				
Input variation influence	0.4% max. (at 85 to 132 VAC input/at 170 to 264 VAC input, 100% load)				
Load variation influence	0.8% max. (with rated input, 0 to 100% load)				
Temperature variation influence (See Note 1.)	0.05%/°C max.				
Rise time	1,000 ms max. (up to 90% of output voltage at rated output voltage/current)				
Hold time (See Note 1.)	20 ms min.				
Additional functions					
Overload protection	105% min., voltage trailing intermittent operation (With the 600-W model, output is turned OFF at 5 s min.)				
Overvoltage protection	Yes				
Overheat protection	No				Yes
Protection-ON alarm indicator	No			Yes (Red)	
Parallel operation	No			Yes, 2 units max.	
Characteristics					
Cooling method	Natural air-cooling				Fan
Ambient temperature	Operating	See the derating curve in the <i>Engineering Data</i> section. (with no condensation or icing)			
	Storage	–25°C to 65°C (-13°F to 149°F) with no condensation or icing			
Ambient humidity	25% to 85%				
Dielectric strength	3.0 kVAC, 50/60 Hz for 1 min (between all inputs and outputs) 2.2 kVAC, 50/60 Hz for 1 min (between all inputs and GR terminals) 1 kVAC, 50/60 Hz for 1 min (between all outputs and GR terminals)				
Insulation resistance	100 MΩ min. (between all output and input/GR terminals at 500 VDC)				
Vibration resistance	10 to 55 Hz, 0.75-mm amplitude for 2 h each in X, Y, and Z directions				
Shock resistance	300 m/s <sup>2</sup> (approx. 30G), 3 times each in ±X, ±Y, and ±Z directions				
Output indicator	Yes (green)				
Electromagnetic interference	Conforms to FCC Class B, EN50081-1				
EMC	(EMI): EN50081-1 Emission Enclosure: EN55022 class B Emission AC Mains: EN55022 class B Harmonic Current: EN61000-3-2 (EMS): EN50082-2 Immunity ESD: EN61000-4-2: 4-kV contact discharge (level 2) 8-kV air discharge (level 3) Immunity RF-interference: ENV50140: 10 V/m (80 MHz to 1 GHz) (level 3) Immunity Conducted Disturbance: ENV50141: 10 V (0.15 to 80 MHz) (level 3) Immunity Burst: EN61000-4-4: 2-kV power-line (level 3) 2-kV output line (level 4) Immunity Surge: EN61000-4-5: between 3-kV lines between 4.5-kV line and FG				
Approved standards	UL508, UL1012, CSA C22.2 No. 950, CSA C22.2 No. 14, EN60950, VDE0160.				
Mean Time Between Failure (MTBF) See Note 2.	135,000 hrs min.				60,000 hrs min.
Weight (See Note 4.)	400 g max.	700 g max.	900 g max.	2,200 g max.	3,500 g max.

- Note: 1. 100% load for rated input voltage (100 VAC or 200 VAC)
2. Mean Time Between Failures is calculated according to the probability of accidental device failures, and indicates reliability of devices. Therefore, it does not necessarily represent a life of the product.
3. The life expectancy shown in the above table indicates average operating hours under the ambient temperature of 40°C and a load rate of 50%. Normally this is determined by the life expectancy of the built-in aluminum electrolytic capacitor. It must be noted that the life expectancy of the fan built into the 600-W model is not included.
4. The weight indicated is for the open-frame type. (Includes the cover for 300-W and 600-W models.)


# Engineering Data

## DERATING CURVE

### Open-frame Type




### Covered Type




- Note: 1. The derating curve shown is for standard installation. The derating curve depends on mounting direction of the Power Supply.  
2. Forced air-cooling must be provided with an air volume of 1 m<sup>3</sup>/min.

## STANDARD INSTALLATION


### 50-W Type




### 100/150-W Type



### 300-W Type



### 600-W Type



## OVERLOAD PROTECTION


### 50- to 300-W Models

The Power Supply has an overload protection function that protects the load and the power supply from possible damage by overcurrent. When the output current rises above a set value (105% of the rated output current), the protection function is triggered, decreasing the output voltage. When the output current falls within the rated range, the overload protection function is automatically cleared.

### 600-W Models

If an excessive current flows for 5 s or more, the output will be turned OFF and simultaneously protection-ON alarm indicator will be lit. To reset the S8PS, turn OFF the input voltage, leave the S8PS for at least three minutes, and then apply the input voltage again.

**Note:** Do not continue using the S8PS with the output terminals short-circuited or the overcurrent condition continued, otherwise the internal elements of the S8PS may be damaged or broken.




## OVERVOLTAGE PROTECTION

The Power Supply has an overvoltage protection function that protects the load and the Power Supply from possible damage by overvoltage. When the output voltage rises above a set value (120% of the rated output voltage), the protection function is triggered, shutting OFF the output voltage. If this occurs, reset the Power Supply by turning it OFF for 1 minute min. and then turning it ON again.

### 300- and 600-W Models

If voltage that is 115% of the rated output voltage or above is output, the output voltage will be turned OFF and simultaneously protection-ON alarm indicator will be lit. To reset the S8PS, turn OFF the input voltage, leave the S8PS for at least one minute and then apply the input voltage again.




## OVERHEAT PROTECTION FUNCTION

### 600-W Model Only

If the internal temperature of the S8PS rises excessively as a result of fan failure or any other reason, the overheat protection circuit will be triggered to protect the internal elements of the S8PS and simultaneously a protection-ON alarm indicator will be lit. To reset the S8PS turn OFF the input voltage, leave the S8PS for at least one minute and then apply the input voltage again.


## ■ INRUSH CURRENT, START UP TIME, HOLD TIME




## Operation

### ■ BLOCK DIAGRAMS


**S8PS-050** (50 W)



**S8PS-10024** (100 W)  
**S8PS-15024** (150 W)  
**S8PS-30024** (300 W)



**S8PS-60024C** (600 W)






# Dimensions

Unit: mm (inch)




## FRONT-MOUNTING BRACKET TYPE

Note: For instructions on how to install the front-mounting brackets, refer to the a subsequent section: *FRONT-MOUNTING BRACKETS*.

**S8PS-050** (50 W)  
**S8PS-050C** (50 W)






**S8PS-10024** (100 W)  
**S8PS-10024C** (100 W)








**S8PS-15024 (150 W)**  
**S8PS-15024C (150 W)**




**S8PS-30024C (300 W)**




Unit: mm (inch)

# **S8PS-60024C (600 W)**



## ■ **FRONT-MOUNTING BRACKETS**



### **50-W Models**




#### **Using the Mounting Bracket**

Attach the Mounting Bracket to the panel and loosely tighten the two screws. Insert the projected parts of the Bracket (b) to the square holes of the power supply (a). Then securely tighten the screws.


#### **Mounting Holes**




### 100/150-W Models Appearance and Mounting Dimensions




### Dimensions with Mounting Bracket




### Using the Mounting Bracket



### 300/600-W Models Appearance and Mounting Dimensions




### Dimensions with Mounting Bracket – 300-W models



### Using the Mounting Bracket


Note: Mounting screws for the Power Supply Unit are provided.

### 300-W models




Note: Mount the Unit 21.6 mm away from the mounting surface in order to provide air ventilation on the rear side.

### Dimensions with Mounting Bracket – 600-W models



### 600-W models






Note: Mount the Unit 28 mm away from the mounting surface in order to provide air ventilation on the rear side.




## ■ DIN-RAIL MOUNTING TYPE

Note: DIN-Rail Mounting Bracket is attached to the Power Supply Unit when the Unit is shipped.




**S8PS-050□□D (50 W)**  
**S8PS-050□□CD (50 W)**



**S8PS-10024D (100 W)**  
**S8PS-10024CD (100 W)**





**S8PS-15024D (150 W)**  
**S8PS-15024CD (150 W)**




Unit: mm (inch)

# **S8PS-30024CD (300 W)**




## ■ DIN-RAIL (ORDER SEPARATELY)

### **PFP-100N/ PFP-50N**




\* For PFP-50N

### **PFP-100N2**




# Installation


## ■ 50-W MODELS




## ■ 100-/150-W MODELS



## ■ 300-W MODELS



## ■ 600-W MODELS



1. **DC Output Terminals:** Connect the load lines to these terminals.
2. **Input Terminals:** Connect the input lines to these terminals.  
Note: A fuse is inserted into the AC (L) side.
3. **Ground Terminal (GR):** Connect a ground line to this terminal.
4. **Output Indicator (DC ON):** Lights while a Direct Current (DC) output is ON.
5. **Output Voltage Adjuster (V.ADJ):** It is possible to increase or decrease the output voltage by 10%.
6. **Protection-ON Alarm Indicator:** The red indicator will be lit if the overvoltage (for a 300-/600-W model) or overheat protection (for a 600-W model) circuit is triggered. This indicator will also be lit when overcurrent (for a 600-W model) is detected.

# Precautions

## ! WARNING


Do not touch the S8PS or heat radiation fin while the power is being supplied or immediately after the power is turned OFF. Otherwise, a skin burn may result from the hot Switching Power Supply or radiator.

## ■ MOUNTING

- When mounting the power supply, allow space for adequate air flow around it – to improve and maintain the reliability of the power supply over a long period of time. The power supply is designed to dissipate heat through natural air-flow.
- Omron recommends mounting the power supply to a metal plate.
- Forced air-cooling is recommended.

## ■ GENERATING OUTPUT VOLTAGE ( $\pm$ )


An output of  $\pm$  can be generated by using two Power Supplies as shown below, because the Power Supply produces a floating output.



## ■ SERIES OPERATION

Only models with power ratings of 100/150 W allow series operation.


As shown in the following diagram, the output voltage from each Switching Power Supply can be added.



## ■ PARALLEL OPERATION

Only 300- and 600-W models can be in parallel operation provided that they are operated under 90% of the ratings. Do not operate any other models in parallel.

Make sure that the thickness and the length of all wires connected to the load are the same to ensure that the wires will have no voltage drop differences.




## ■ FAN REPLACEMENT

The service life of the fan is approximately 50,000 hours (at 25°C). The service life varies, however, depending on the ambient temperature or other surrounding environmental conditions such as dust. As a preventive maintenance measure, replace the fan within two years if it is used at an ambient temperature of 40°C.

Fans are available as replacements.


Model: S82Y-JFAN



Fan Set:

Fan (above), four M4 x 35 sems screws, instruction sheet, and packing case>

Replace the fan as shown in the following illustration.



## Certain Terms and Conditions of Sale

1. **Offer; Acceptance.** These terms and conditions (these "Terms") are deemed part of all catalogs, manuals or other documents, whether electronic or in writing, relating to the sale of goods or services (collectively, the "Goods") by Omron Electronics LLC and its subsidiary companies ("Seller"). Seller hereby objects to any terms or conditions proposed in Buyer's purchase order or other documents which are inconsistent with, or in addition to, these Terms. Please contact your Omron representative to confirm any additional terms for sales from your Omron company.
2. **Prices.** All prices stated are current, subject to change without notice by Seller. Buyer agrees to pay the price in effect at time of shipment.
3. **Discounts.** Cash discounts, if any, will apply only on the net amount of invoices sent to Buyer after deducting transportation charges, taxes and duties, and will be allowed only if (i) the invoice is paid according to Seller's payment terms and (ii) Buyer has no past due amounts owing to Seller.
4. **Orders.** Seller will accept no order less than \$200 net billing.
5. **Governmental Approvals.** Buyer shall be responsible for, and shall bear all costs involved in, obtaining any government approvals required for the importation or sale of the Goods.
6. **Taxes.** All taxes, duties and other governmental charges (other than general real property and income taxes), including any interest or penalties thereon, imposed directly or indirectly on Seller or required to be collected directly or indirectly by Seller for the manufacture, production, sale, delivery, importation, consumption or use of the Goods sold hereunder (including customs duties and sales, excise, use, turnover and license taxes) shall be charged to and remitted by Buyer to Seller.
7. **Financial.** If the financial position of Buyer at any time becomes unsatisfactory to Seller, Seller reserves the right to stop shipments or require satisfactory security or payment in advance. If Buyer fails to make payment or otherwise comply with these Terms or any related agreement, Seller may (without liability and in addition to other remedies) cancel any unshipped portion of Goods sold hereunder and stop any Goods in transit until Buyer pays all amounts, including amounts payable hereunder, whether or not then due, which are owing to it by Buyer. Buyer shall in any event remain liable for all unpaid amounts.
8. **Cancellation; Etc.** Orders are not subject to rescheduling or cancellation unless Buyer indemnifies Seller fully against all costs or expenses arising in connection therewith.
9. **Force Majeure.** Seller shall not be liable for any delay or failure in delivery resulting from causes beyond its control, including earthquakes, fires, floods, strikes or other labor disputes, shortage of labor or materials, accidents to machinery, acts of sabotage, riots, delay in or lack of transportation or the requirements of any government authority.
10. **Shipping; Delivery.** Unless otherwise expressly agreed in writing by Seller:
  - a. Shipments shall be by a carrier selected by Seller;
  - b. Such carrier shall act as the agent of Buyer and delivery to such carrier shall constitute delivery to Buyer;
  - c. All sales and shipments of Goods shall be FOB shipping point (unless otherwise stated in writing by Seller), at which point title to and all risk of loss of the Goods shall pass from Seller to Buyer, provided that Seller shall retain a security interest in the Goods until the full purchase price is paid by Buyer;
  - d. Delivery and shipping dates are estimates only.
  - e. Seller will package Goods as it deems proper for protection against normal handling and extra charges apply to special conditions.
11. **Claims.** Any claim by Buyer against Seller for shortage or damage to the Goods occurring before delivery to the carrier must be presented in writing to Seller within 30 days of receipt of shipment and include the original transportation bill signed by the carrier noting that the carrier received the Goods from Seller in the condition claimed.
12. **Warranties.** (a) **Exclusive Warranty.** Seller's exclusive warranty is that the Goods will be free from defects in materials and workmanship for a period of twelve months from the date of sale by Seller (or such other period expressed in writing by Seller). Seller disclaims all other warranties, express or implied. (b) **Limitations.** SELLER MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, ABOUT NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OF THE GOODS. BUYER ACKNOWLEDGES THAT IT ALONE HAS DETERMINED THAT THE GOODS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE. Seller further disclaims all warranties and responsibility of any type for claims or expenses based on infringement by the Goods or otherwise of any intellectual property right. (c) **Buyer Remedy.** Seller's sole obligation hereunder shall be to replace (in the form originally shipped with Buyer responsible for labor charges for removal or replacement thereof) the non-complying Good or, at Seller's election, to repay or credit Buyer an amount equal to the purchase price of the Good; provided that in no event shall Seller be responsible for warranty, repair, indemnity or any other claims or expenses regarding the Goods unless Seller's analysis confirms that the Goods were properly handled, stored, installed and maintained and not subject to contamination, abuse, misuse or inappropriate modification. Return of any goods by Buyer must be approved in writing by Seller before shipment. Seller shall not be liable for the suitability or unsuitability or the results from the use of Goods in combination with any electrical or electronic components, circuits, system assemblies or any other materials or substances or environments. Any advice, recommendations or information given orally or in writing, are not to be construed as an amendment or addition to the above warranty.
13. **Damage Limits; Etc.** SELLER SHALL NOT BE LIABLE FOR SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR PRODUCTION OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE GOODS, WHETHER SUCH CLAIM IS BASED IN CONTRACT, WARRANTY, NEGLIGENCE OR STRICT LIABILITY. Further, in no event shall liability of Seller exceed the individual price of the Good on which liability is asserted.
14. **Indemnities.** Buyer shall indemnify and hold harmless Seller, its affiliates and its employees from and against all liabilities, losses, claims, costs and expenses (including attorney's fees and expenses) related to any claim, investigation, litigation or proceeding (whether or not Seller is a party) which arises or is alleged to arise from Buyer's acts or omissions under these Terms or in any way with respect to the Goods. Without limiting the foregoing, Buyer (at its own expense) shall indemnify and hold harmless Seller and defend or settle any action brought against Seller to the extent that it is based on a claim that any Good made to Buyer specifications infringed intellectual property rights of another party.
15. **Property; Confidentiality.** The intellectual property embodied in the Goods is the exclusive property of Seller and its affiliates and Buyer shall not attempt to duplicate it in any way without the written permission of Seller. Notwithstanding any charges to Buyer for engineering or tooling, all engineering and tooling shall remain the exclusive property of Seller. All information and materials supplied by Seller to Buyer relating to the Goods are confidential and proprietary, and Buyer shall limit distribution thereof to its trusted employees and strictly prevent disclosure to any third party.
16. **Miscellaneous.** (a) **Waiver.** No failure or delay by Seller in exercising any right and no course of dealing between Buyer and Seller shall operate as a waiver of rights by Seller. (b) **Assignment.** Buyer may not assign its rights hereunder without Seller's written consent. (c) **Amendment.** These Terms constitute the entire agreement between Buyer and Seller relating to the Goods, and no provision may be changed or waived unless in writing signed by the parties. (d) **Severability.** If any provision hereof is rendered ineffective or invalid, such provision shall not invalidate any other provision. (e) **Setoff.** Buyer shall have no right to set off any amounts against the amount owing in respect of this invoice. (f) As used herein, "including" means "including without limitation".

## Certain Precautions on Specifications and Use

1. **Suitability of Use.** Seller shall not be responsible for conformity with any standards, codes or regulations which apply to the combination of the Good in the Buyer's application or use of the Good. At Buyer's request, Seller will provide applicable third party certification documents identifying ratings and limitations of use which apply to the Good. This information by itself is not sufficient for a complete determination of the suitability of the Good in combination with the end product, machine, system, or other application or use. The following are some examples of applications for which particular attention must be given. This is not intended to be an exhaustive list of all possible uses of this Good, nor is it intended to imply that the uses listed may be suitable for this Good:
  - (i) Outdoor use, uses involving potential chemical contamination or electrical interference, or conditions or uses not described in this document.
  - (ii) Energy control systems, combustion systems, railroad systems, aviation systems, medical equipment, amusement machines, vehicles, safety equipment, and installations subject to separate industry or government regulations.
  - (iii) Systems, machines and equipment that could present a risk to life or property. Please know and observe all prohibitions of use applicable to this Good.

NEVER USE THE PRODUCT FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE SELLER'S PRODUCT IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.
2. **Programmable Products.** Seller shall not be responsible for the user's programming of a programmable Good, or any consequence thereof.
3. **Performance Data.** Performance data given in this catalog is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of Seller's test conditions, and the user must correlate it to actual application requirements. Actual performance is subject to the Seller's Warranty and Limitations of Liability.
4. **Change in Specifications.** Product specifications and accessories may be changed at any time based on improvements and other reasons. It is our practice to change part numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the Good may be changed without any notice. When in doubt, special part numbers may be assigned to fix or establish key specifications for your application. Please consult with your Seller's representative at any time to confirm actual specifications of purchased Good.
5. **Errors and Omissions.** The information in this catalog has been carefully checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical or proofreading errors, or omissions.



Complete "Terms and Conditions of Sale" for product purchase and use are on Omron's website at [www.omron.com/oei](http://www.omron.com/oei) – under the "About Us" tab, in the Legal Matters section.

**ALL DIMENSIONS SHOWN ARE IN MILLIMETERS.**

To convert millimeters into inches, multiply by 0.03937. To convert grams into ounces, multiply by 0.03527.

---

**OMRON**<sup>®</sup>

**OMRON ELECTRONICS LLC**

One Commerce Drive  
Schaumburg, IL 60173

**847-843-7900**

For US technical support or other inquiries:

**800-556-6766**

**OMRON CANADA, INC.**

885 Milner Avenue  
Toronto, Ontario M1B 5V8

**416-286-6465**

**OMRON ON-LINE**

Global - <http://www.omron.com>  
USA - <http://www.omron.com/oei>  
Canada - <http://www.omron.ca>