

**H8/3854 Series  
Expansion Board  
(HS3854EIO60H)  
for E6000 Emulator**

User's Manual



HS3854EIO60HE(B)

## Cautions

1. Renesas neither warrants nor grants licenses of any rights of Renesas's or any third party's patent, copyright, trademark, or other intellectual property rights for information contained in this document. Renesas bears no responsibility for problems that may arise with third party's rights, including intellectual property rights, in connection with use of the information contained in this document.
2. Products and product specifications may be subject to change without notice. Confirm that you have received the latest product standards or specifications before final design, purchase or use.
3. Renesas makes every attempt to ensure that its products are of high quality and reliability. However, contact Renesas's sales office before using the product in an application that demands especially high quality and reliability or where its failure or malfunction may directly threaten human life or cause risk of bodily injury, such as aerospace, aeronautics, nuclear power, combustion control, transportation, traffic, safety equipment or medical equipment for life support.
4. Design your application so that the product is used within the ranges guaranteed by Renesas particularly for maximum rating, operating supply voltage range, heat radiation characteristics, installation conditions and other characteristics. Renesas bears no responsibility for failure or damage when used beyond the guaranteed ranges. Even within the guaranteed ranges, consider normally foreseeable failure rates or failure modes in semiconductor devices and employ systemic measures such as fail-safes, so that the equipment incorporating Renesas product does not cause bodily injury, fire or other consequential damage due to operation of the Renesas product.
5. This product is not designed to be radiation resistant.
6. No one is permitted to reproduce or duplicate, in any form, the whole or part of this document without written approval from Renesas.
7. Contact Renesas's sales office for any questions regarding this document or Renesas semiconductor products.

## Preface

Thank you for purchasing this H8/3854 series expansion board (HS3854EIO60H; hereinafter referred to as the expansion board) for the H8/300L series E6000 emulator.


The expansion board enables user systems for Renesas's original microcomputer H8/3854 series to be developed using an H8/300L series E6000 emulator (HS3L08EPI60H; hereinafter referred to as the emulator) and the H8/3834 evaluation chip set (HS3834EVI60H).

## Contents

Section 1 Components .....	1
Section 2 Connection Procedures .....	2
2.1 Using Emulator without Connecting User System .....	2
2.2 Using Emulator with Connecting User System through User System Interface Cable ....	2
Section 3 Reset Switch .....	4
Section 4 Notice .....	5

## Section 1 Components

Figure 1 shows the HS3854EIO60H expansion board appearance, and table 1 lists the components of the expansion board. Please make sure you have all of these components when unpacking.



**Figure 1 HS3854EIO60H Expansion Board**

**Table 1 HS3854EIO60H Components**

No.	Component	Quantity	Remarks
1	HS3854EIO60H	1	Expansion board
2	Documentation	1	User's manual for HS3854EIO60H (this manual)

## Section 2 Connection Procedures

### **WARNING**

**Always switch OFF the user system and the emulator product before the EXPANSION BOARD or USER SYSTEM INTERFACE CABLE is connected to or removed from any part.**

**Before connecting, make sure that pin 1 on each side is correctly aligned. Failure to do so will result in a FIRE HAZARD and will damage the user system, the emulator product, the user system interface cable, and the expansion board, or will result in PERSONAL INJURY. The USER PROGRAM will be LOST.**

### **2.1 Using Emulator without Connecting User System**

1. Make sure the emulator is turned off.
2. After making sure the direction of the expansion board connector labeled E6000 EMULATOR is correct, firmly insert the expansion board connector into the emulator station connector. When the emulator is operated while connected to only the expansion board (without connecting the user system), disconnect the cable body from the expansion board.

### **2.2 Using Emulator with Connecting User System through User System Interface Cable**


### **CAUTION**

**When connecting or removing the user system interface cable, apply force only in the direction suitable for connection or removal, while making sure not to bend or twist the cable or connectors.**

**Otherwise, the cables or connectors will be damaged.**

1. Make sure the emulator and the user system are turned off.

2. [1] After making sure the direction of the expansion board connector labeled E6000 EMULATOR is correct, firmly insert the expansion board connector into the emulator station connector ([1] in figure 2).
- [2] Connect the expansion board labeled USER INTERFACE CABLE and the user system interface cable body.



**Figure 2 Connecting Expansion Board to Emulator Station and User System Interface Cable**

## Section 3 Reset Switch

The reset switch is on the side of the expansion board as shown in figure 2. Pressing the reset switch resets the H8/3854 dot-matrix LCD controller (table 2).

**Table 2** Reset Types for the Emulator

Reset Type	Condition	H8/3854 Dot-Matrix LCD Controller	H8/3854 CPU and I/O other than LCD Controller
HDI reset commands	Reset CPU Go Reset	—	R
Reset input from the user system during user program execution	User reset is masked by configuration setting	R	—
	User reset is not masked by configuration setting	R	R
H8/3854 expansion board reset switch	Reset switch is pressed	R	—
Emulator power on	Emulator is turned on	R	R

R: Reset is valid, —: Reset is invalid

## Section 4 Notice

### **WARNING**

- 1. This expansion board is specifically designed for the HS3L08EPI60H emulator and the HS3834EVI60H evaluation chip set. Do not use this expansion board with any other emulator station.**
- 2. Use the H8/3854 series user system interface cable (HS3854ECH61H for FP-100B or HS3854ECN61H for TFP-100G). Do not use any other series of user system interface cable.**

1. Do not place heavy objects on the expansion board.  
2. Power is supplied from the emulator station to the expansion board.

3. To open the case of the expansion board, remove the four screws on the top panel. To close the case, place the top panel on the expansion board, and fix it with the four screws.




Figure 3 Removing Expansion Board Upper Panel

## **WARNING**

**When using a polarized capacitor, make sure that the polarity is correct when installing the capacitor. Failure to do so will result in a FIRE HAZARD and will damage the user system, the emulator product, the user system interface cable, and the expansion board, or will result in PERSONAL INJURY.**

4. To prevent breaking of wires in the expansion board, do not place heavy or sharp metal objects on the expansion board while the case is open.