




15A (2C), 10A (4C) COMPACT **POWER RELAYS WITH HIGH SENSITIVITY**

SP RELAYS



FEATURES

• High Vibration/Shock Resistance

Vibration resistance: 18 G, amplitude 3 mm (10 to 55 Hz) Shock resistance: 40 G (11 ms)

- · Latching types available
- High Sensitivity in Small Size 150 mW pick-up, 300 mW nominal operating power
- Wide Switching Range From 1 mA to 15 A (2C) and 10 A (4C)

SPECIFICATIONS

Contacts

Contacts	•						
Arrangement				2 Form C, 4 Form C			
Initial contact resistance, max. (By voltage drop 6 V DC 1 A)				30 mΩ			
Initial contact pressure				2C: Approx. 0.392 N (40 g 1.41 oz) 4C: Approx. 0.196 N (20 g 0.71 oz)			
Contact material				Stationary contact: Gold flashed silver alloy			
				Movable contact: Silver alloy			
Rating (resistive load)	Nominal swit	ching	capacity	2C: 15 A 250 V AC 10 A 30 V DC 4C: 10 A 250 V AC 10 A 30 V DC			
	Max. switching	ng pov	ver	2C: 3,750 VA, 300 W 4C: 2,500 VA, 300 W			
	Max. switching	ng volt	age	2C, 4C: 250 V AC, 30 V DC			
	Max. switching	ng cur	rent	2C: 15 A (AC) 10 A (DC), 4C: 10 A			
	Min. switchin	g cap	acity#1	100 mA, 5 V DC			
Expected life (min. operations)	Mechanical (at 180 cpm)			5 × 10 ⁷			
	Electrical (at 20 cpm) (resistive	2C	15 A 250 V AC	10⁵			
			10 A 30 V DC	10⁵			
		4C	10 A 250 V AC	10⁵			
	load)	40	10 A 30 V DC	105			

Coil (polarized) at 20°C 68°F

Single side stable	Nominal operating power	300 mW
Latabina	Minimum set and reset power	150 mW
Latching	Nominal set and reset power	300 mW

Characteristics (at 25°C 77°F 50% Relative humidity)

Citatacteris	olics (al	23 6 77 1 30	76 Helative Humburly)			
Max. operating	g speed (at	rated load)	20 cpm			
Initial insulatio	n resistano	ce*1	1,000 MΩ at 500 V DC			
Initial	Between	open contacts	1,500 Vrms			
breakdown	Between	contact sets	3,000 Vrms			
voltage*2	Between	contact and coil	3,000 Vrms			
Operate time*	at nomina	al voltage)	Max. 30 ms (Approx. 25 ms)			
Release time((at nominal vo		de)*3	Max. 20 ms (Approx. 15 ms)			
Temperature r (at nominal vo			Max. 40°C with nominal coil voltage and at nominal switching capacity			
Shock resistance		Functional*4	Min. 392 m/s ² {40 G}			
		Destructive*5	Min. 980 m/s ² {100 G}			
Vibration resistance		Functional*6	176.4 m/s ² {18 G}, 10 to 55 Hz at double amplitude of 3 mm			
		Destructive	176.4 m/s ² {18 G}, 10 to 55 Hz a double amplitude of 3 mm			
Conditions for operation, transport and storage*7 (Not freezing and condens- ing at low temperature)		Ambient temp.	−50°C to +60°C −58°F to +140°F			
		Humidity	5 to 85% R.H.			
Unit weight			2C: 50 g 1.76 oz ; 4C: 65 g 2.29 oz			

^{#1} This value can change due to the switching frequency, environmental conditions, and desired reliability level, therefore it is recommended to check this with the actual load


Remarks

- Specifications will vary with foreign standards certification ratings.
- *1 Measurement at same location as "Initial breakdown voltage" section
- *2 Detection current: 10 mA
- *3 Excluding contact bounce time
- *4 Half-wave pulse of sine wave: 11ms; detection time: 10μs
- *5 Half-wave pulse of sine wave: 6ms
- *6 Detection time: 10μs
- *7 Refer to 6. Conditions for operation, transport and storage mentioned in AMBIENT ENVIRONMENT

TYPICAL APPLICATIONS

ORDERING INFORMATION

NC machines, remote control panels, sophisticated business equipment.



(Notes) 1. PC board terminal types available as option. Please consult us for details.

- 2. 2 Form C: Carton: 20 pcs., Case: 200 pcs.
- 4 Form C: Carton: 10 pcs., Case: 100 pcs.
- 3. UL/CSA, TÜV approved type is standard.
- 1 coil latching type available.

TYPES AND COIL DATA (at 20°C 68°F)

Single side stable

Part No.		Nominal	Pick-up	Drop-out	Nominal	Coil resis-	Inductance,	Nominal	Maximum allowable
2 Form C	4 Form C	voltage, V DC	voltage, V DC (max.)	voltage, V DC (min.)	operating current, mA	tance, Ω (±10%) 20°C	H (at 120 Hz)	operating power, mW	voltage, V DC (40°C)
SP2-DC3V	SP4-DC3V	3	2.1	0.3	100.0	30	Approx. 0.05	300	4.5
SP2-DC5V	SP4-DC5V	5	3.5	0.5	60.2	83	0.1	300	7.5
SP2-DC6V	SP4-DC6V	6	4.2	0.6	50.0	120	0.2	300	9
SP2-DC12V	SP4-DC12V	12	8.4	1.2	25.0	480	0.7	300	18
SP2-DC24V	SP4-DC24V	24	16.8	2.4	12.5	1,920	3.0	300	36
SP2-DC48V	SP4-DC48V	48	33.6	4.8	6.2	7,700	11.2	300	72


2-coil latching

Part No.		Nominal voltage,		Nominal operating	Coil resistance, Ω (±10%)		Inductance, H (at 120 Hz)		Nominal operating	Maximum allowable
2 Form C	4 Form C	Voltage, V DC	voltage, V DC (max.)	current, mA	Coil I	Coil II	Coil I	Coil II	nower mW	voltage, V DC (40°C)
SP2-L2-DC3V	SP4-L2-DC3V	3	2.1	100.0	30	30	Approx. 0.03	Approx. 0.03	300	4.5
SP2-L2-DC5V	SP4-L2-DC5V	5	3.5	60.2	83	83	0.07	0.07	300	7.5
SP2-L2-DC6V	SP4-L2-DC6V	6	4.2	50.0	120	120	0.1	0.1	300	9
SP2-L2-DC12V	SP4-L2-DC12V	12	8.4	25.0	480	480	0.4	0.4	300	18
SP2-L2-DC24V	SP4-L2-DC24V	24	16.8	12.5	1,920	1,920	1.4	1.4	300	36
SP2-L2-DC48V	SP4-L2-DC48V	48	33.6	6.2	7,680	7,680	5.6	5.6	300	72

DIMENSIONS mm inch

2 Form C

Plug-in terminal



General tolerance: $\pm 0.3 \pm .012$

Schematic (Bottom view) Single side stable



(Deenergized condition)

2 coil latching




(Reset condition)

Diagram shows the "reset" position when terminals 3 and 4 are energized. Energize terminals 1 and 2 to transfer contacts.


4 Form C

Plug-in terminal




General tolerance: ±0.3 ±.012

Schematic (Bottom view) Single side stable



(Deenergized condition)

2 coil latching




(Reset condition)

Diagram shows the "reset" position when terminals 3 and 4 are energized. Energize terminals 1 and 2 to transfer contacts.

REFERENCE DATA

Operate and release time (Single side stable) SP2



SE 40
Operate time
30
Release time
Min
Max
Min

Coil applied voltage, %V

SP4


Sample: SP2-DC24V
Ambient temperature: 20 to 22°C 68 to 72°F

Coil temperature rise


10

0

Sample: SP4-DC24V Ambient temperature: 27 to 29°C 81 to 84°F



Electrical life (SP2, 15 A 250 V AC resistive load)





Max. N.C. N.O. Max. Max. X. Min. Min. Min. Min. No. of operations, ×10⁴

19.2 21.6 24.0 26.4 28.8 31.2 33.6 36.0

Coil applied voltage,%V

Electrical life (SP4, 10 A 250 V AC resistive load)







ACCESSORIES mm inch

Soldering socket


SP2-SS




SP4-SS




Wrapping socket



SP4-WS



Mounting hole drilling diagram



Performance profile

Item	SP2, socket with solder	SP4, socket with solder	SP2, wrap- ping socket	SP4, wrap- ping socket			
Withstand voltage	AC 3,000V, 1 min., between each terminal						
Insulation resistance	1,000 MΩ min						
Ambient working temperature	−50 to +60°C −58 to +140°F						
Maximum current, ON current	15 A	10 A	12 A	10 A			

Note: Do not remove the relay while it is ON.

Notes:

(1) Mounting screws and the fastening bracket are included in the package.

(2) Mount the relay with the proper mounting direction — i.e. with the direction of the NAIS mark on top of the

relay case matching the direction of the NAIS mark on the terminal block. (The 介 direction of the terminal block is the upward direction of the relay.)


Mounting and removal of fastening bracket

1. Mounting


Insert the A part of the fastening bracket into the mounting groove of the socket, and then fit the B part into groove, while pressing with the tip of a minus screwdriver.

2. Removal


Slide the B part of the fastening bracket from the groove in the socket, while pressing with the tip of a minus screwdriver. While the bracket is in this position, keep pressing the C part of the bracket to the relay side with your finger, and lift up to the left side and remove from the groove, as in the diagram at right.



Screw terminal socket



Mounting hole drilling diagram



Notes:

(1) Mounting screws and the fastening bracket are included in the package.

(2) Mount the relay with the proper mounting direction — i.e. with the direction of the NAIS mark on top of the relay case matching the direction of the NAIS mark on the terminal block. (The ${\mitchirple}$ direction of the terminal block is the upward direction of the relay.)

Fastening bracket mounting and removal


1. Mounting

Insert the A part of the fastening bracket into the mounting groove of the terminal block, and then fit the B part into groove, while pressing with the tip of a minus screwdriver.


2. Removal

Slide the B part of the fastening bracket from the groove in the terminal block, while pressing with the tip of a minus screwdriver. While the bracket is in this position, keep pressing the C part of the bracket to the relay side with your finger,


and lift up to the left side and remove from the groove, as in the diagram at right.



Mounting plate



The SP-Relay with SP-MA attached



Tolerance: ±0.1 ±.004



Direct chassis mounting possible, and applicable to DIN rail. [DIN 46277 (35 mm width) is applicable.]

SP

Use method


- 1. Both the SP relay 2c and 4c can be mounted to the mounting slats.
- 2. Use the mounting slats either by attaching them directly to the chassis, or by mounting with a DIN rail.
- (A) When attaching directly to chassis Use two M3 screws.

For the mounting pitch, refer to the specification diagram.

(B) When mounting on a DIN rail Use a 35mm 1.378inch wide DIN rail (DIN46277).

The mounting method should be as indicated in the diagram at right.

Method for mounting on DIN rail



- (1) First fit the arc shaped claw of the mounting slat into the DIN rail.
- (2) Press on the side as shown in the diagram below.
- (3) Fit in the claw part on the opposite side.

Precautions for use

When mounting to a DIN rail, use a commercially available fastening bracket if there is a need to stop sliding of the mounting slat in the rail direction.

For Cautions for Use, see Relay Technical Information